

used include ash, lime, sawdust, dried soil or dried agricultural waste products. Urine diversion toilet seats or squatting pans can be obtained or produced locally.

Applicability: